



DATASHEET

SCREWDRIVER

v1.4



Telefon: +420 416 711 333 E-mail: lin-tech@hennlich.cz



1. Datasheet

1.1. Screwdriver

| General Properties | | Minimum | Typical | Maximum | Unit | |
|---------------------------------|-----------------------------------|---------------------------|------------------------------|---------|--------|--|
| Tightoning town a von | | 0.15 | | 5 | [Nm] | |
| Tightening torque range | ge | 0.11 | - | 3.68 | [lbft] | |
| Tightening torque | If torque < 1.33 Nm/ | | 0.04 | | [Nm] | |
| | 0.98 lbft | - | 0.03 | - | [lbft] | |
| accuracy* | If torque > 1.33 Nm/ 0.98 lbft | - | 3 | - | [%] | |
| Self-tapping torque | | - | 85% of the tightening torque | 3 | [Nm] | |
| Pre-mount accuracy error** | | - | - | 0.5 | [mm] | |
| Output speed | | - | - | 340 | [RPM] | |
| Screw length within full safety | | - | | 35 | [mm] | |
| | | | _ | 1.37 | [inch] | |
| Shank stroke (screw axis) | | | _ | 55 | [mm] | |
| Stidik sticke (sciew a | Al5) | - | _ | 2.16 | [inch] | |
| Shank preload (adjust | able) | 0 | 10 | 25 | [N] | |
| Protective feature force | e | 35 | 40 | 45 | [N] | |
| Storage temperature | | 0 | - | 60 | [°C] | |
| Storage temperature | | 32 | - | 140 | [°F] | |
| Motor (x2) | | Integrated, electric BLDC | | | | |
| IP Classification | | IP54 | | | | |
| ESD Safe | | Yes | | | | |
| Dimensions | | 308 x 86 | × 114 | | [mm] | |
| Difficusions | | 12.1 x 3.4 x 4.5 | | | | |
| Weight | | 2.5 | | | [kg] | |
| wweight | | 5.51 | | | [lb] | |

^{*} See Torque Accuracy Graph for further information.

^{**} The pitch of the screw might contribute to the total pre-mount accuracy error.

| Operating Conditions | Minimum | Typical | Maximum | Unit |
|----------------------|---------|---------|---------|------|
| Power supply | 20 | 24 | 25 | [V] |
| Current consumption | 75 | - | 4500 | [mA] |





| Operating Conditions | Minimum | Typical | Maximum | Unit |
|------------------------------------|---------|---------|---------|---------|
| Operating temperature | 5 | - | 50 | [°C] |
| Operating temperature | 41 | - | 122 | [°F] |
| Relative humidity (non-condensing) | 0 | - | 95 | [%] |
| Calculated operation life | 30 000 | - | - | [Hours] |

Supported Screws

| Supported Screws Metric | | | | | | | | |
|-------------------------|--|-------------------|----------------------------------|-----------|-----------|-----------|--|--|
| Material typ | Material type Magnetic | | | | | | | |
| Screw leng | Screw length Up to 50 mm (35 mm thread length) | | | | | | | |
| Head type | | | Cylinder Counter sunk Button hea | | | | | |
| Appearanc | e | | | | | | | |
| | | | 0 | 0 | | | | |
| Standard | | Din 912 / SO 4762 | ISO 14579 | ISO 14580 | ISO 14581 | DIN 7985A | | |
| | M1.6 | √ | N/A | N/A | N/A | N/A | | |
| | M2 | √ | √ | N/A | ✓ | ✓ | | |
| Common and and | M2.5 | √ | ✓ | N/A | ✓ | ✓ | | |
| Supported Thread | М3 | √ | √ | ✓ | ✓ | ✓ | | |
| Size | M4 | √ | √ | ✓ | ✓ | ✓ | | |
| | M5 | √ | ✓ | ✓ | ✓ | ✓ | | |
| | М6 | ✓ | ✓ | ✓ | ✓ | ✓ | | |

| | Supported Screws US Standard | |
|---------------|------------------------------|--|
| Material type | Magnetic | |

Telefon: +420 416 711 333 E-mail: lin-tech@hennlich.cz



| | Supported Screws US Standard | | | | | | | |
|----------------|------------------------------|----------------------|--------------------|-----------------|---|--|--|--|
| Screw leng | ıth | Up to 1.96 inch | es (1.37 inches th | read length) | | | | |
| Head type | | Cylinder Button head | | Counte | er sunk | | | |
| Appearanc | e | | | | PERSONAL PROPERTY OF THE PERSONAL PROPERTY OF | PROTECTION OF THE PROTECTION O | | |
| Standard | | ASME B18.3 | ASME B18.6.3 | ASME B18.6.3 | ASME B18.3 | ASME B18.6.3 | | |
| | 1# | ✓ | N/A | N/A | N/A | N/A | | |
| | 2# | √ | √ | √ | N/A | √ | | |
| | 4# | √ | ✓ | √ | ✓ | ✓ | | |
| Supported | 6# | √ | ✓ | ✓ | ✓ | ✓ | | |
| Thread Size | 8# | √ | ✓ | √ | ✓ | √ | | |
| | 10# | √ | ✓ | √ | ✓ | ✓ | | |
| | 12# | N/A | ✓ | √ | N/A | N/A | | |
| | 1/4" | √ | N/A | N/A | √ | N/A | | |

| Supported Self-tapping Screws for Aluminium 1/2 | | | | | | |
|---|---|-------------------|--|--|--|--|
| Material type | Magnetic | | | | | |
| Screw length | Up to 50 mm (35 n | nm thread length) | | | | |
| Head type | Pan head Flat round with Lens head flange | | | | | |
| Appearance | | | | | | |



| Su | Supported Self-tapping Screws for Aluminium 1/2 | | | | | | |
|--|---|-------------------------|----------|------------|--|--|--|
| Standard | DIN 7981 C/ ISO 7049 | DIN 7981 F/ ISO 7049 | WN 5251 | DIN 7983 C | | | |
| Thread size and Bit holder/ Bit extender | Bit, screw carrier and screw fix needed | | | | | | |
| ST2.2 / 2.2 / KB22 / K22 | √ | ✓ | N/A | ✓ | | | |
| ST 2.9 | ✓ | √ | N/A | ✓ | | | |
| 3 / M3 / KB30 / K30 | N/A | N/A | ✓ | N/A | | | |
| ST3.5.3 / 3.5 / KB35 / K35 | √ | ✓ | √ | √ | | | |
| ST 3.9 | N/A | ✓ | N/A | N/A | | | |
| 4 / M4 / KB40 / K40 | N/A | N/A | ✓ | N/A | | | |
| ST 4.2 | ✓ | ✓ | N/A | ✓ | | | |
| ST 4.8 | ✓ | N/A | N/A | ✓ | | | |
| 50 / M5 / KB50 / K50 | N/A | N/A | ✓ | N/A | | | |
| ST 5.5 | √ | N/A | N/A | N/A | | | |
| ST 6.3 | ✓ | N/A | N/A | N/A | | | |

| Supported Self-tapping Screws for Aluminium 2/2 | | | | | | |
|---|---|-----------------|------------|--|--|--|
| Material type | Magnetic | | | | | |
| Screw length | Up to 50 mm (3 | 35 mm thread le | ngth) | | | |
| Head type | | Counter sunk | | | | |
| Appearance | | | | | | |
| Standard | DIN 7500 M | DIN 14586 C | DIN 7982 C | | | |
| Thread size and Bit holder/ Bit extender | Bit, screw carrier and screw fix needed | | | | | |
| 20 / M2 / K20 | ✓ | N/A | N/A | | | |
| ST2.2 / 2.2 / KB22 / K22 | N/A | ✓ | √ | | | |

Telefon: +420 416 711 333



| Supported Self-tapping Screws for Aluminium 2/2 | | | | | | |
|---|-----|-----|----------|--|--|--|
| 2.5 / M2.5 / KB25 / K25 | ✓ | N/A | N/A | | | |
| ST 2.9 | N/A | ✓ | ✓ | | | |
| 3 / M3 / KB30 / K30 | ✓ | N/A | N/A | | | |
| ST3.5.3 / 3.5 / KB35 / K35 | N/A | ✓ | ✓ | | | |
| ST 3.9 | N/A | ✓ | ✓ | | | |
| 4 / M4 / KB40 / K40 | ✓ | N/A | N/A | | | |
| ST 4.2 | N/A | ✓ | ✓ | | | |
| ST 4.8 | N/A | ✓ | ✓ | | | |
| 50 / M5 / KB50 / K50 | ✓ | N/A | N/A | | | |
| ST 5.5 | N/A | ✓ | ✓ | | | |
| 60 / M6 | ✓ | N/A | N/A | | | |
| ST 6.3 | N/A | ✓ | ✓ | | | |

| Supported Self-tapping Screws for Plastic | | | | | |
|---|----------------------|---------------|-------------|--|--|
| Material type | Magnetic | | | | |
| Screw length | Up to 50 mm (35 ı | mm thread ler | ngth) | | |
| Head type | Counter sunk | Flat round | with flange | | |
| Appearance | | | | | |
| Standard | ISO 4042 | WN 1411 | WN 5451 | | |
| Thread size and Bit holder/ Bit extender | Bit, screw carrier a | and screw fix | needed | | |
| 20 / M2 / K20 | N/A | N/A | ✓ | | |
| ST2.2 / 2.2 / KB22 / K22 | ✓ | N/A | √ | | |
| 2.5 / M2.5 / KB25 / K25 | √ | ✓ | √ | | |
| 3 / M3 / KB30 / K30 | ✓ | ✓ | √ | | |



| Supported Self-tapping Screws for Plastic | | | | | |
|---|-----|-----|----------|--|--|
| ST3.5.3 / 3.5 / KB35 / K35 | ✓ | ✓ | N/A | | |
| 4 / M4 / KB40 / K40 | ✓ | ✓ | ✓ | | |
| 50 / M5 / KB50 / K50 | N/A | ✓ | ✓ | | |
| 60 / M6 | N/A | N/A | ✓ | | |

Guidance on Achievable Depth for Self-tapping Screws

How deep a screw can be self-tapped highly depends on the screw material and the workpiece material. There are three examples below of what the maximum depth is for a specific screw to go into a specific material.

Example of WN 1411 in POM

| Screw Size | Depth |
|------------|-------|
| K18x10 | 10 |
| K20x10 | 10 |
| K22x16 | 16 |
| K25x16 | 16 |
| K30x20 | 20 |
| K35x30 | 30 |
| K40x30 | 30 |
| K50x30 | 30 |

Example of WN 1411 in NYLON PA Type 6

| Screw Size | Depth |
|------------|-------|
| K18x10 | 10 |
| K20x10 | 10 |
| K22x16 | 16 |
| K25x16 | 16 |
| K30x20 | 20 |



Telefon: +420 416 711 333

E-mail: lin-tech@hennlich.cz



| Screw Size | Depth |
|------------|-------|
| K35x30 | 30 |
| K40x30 | 30 |
| K50x30 | 30 |

Example of DIN 7500 M in Aluminium EN AW-5754

| Screw Size | Depth |
|------------|-------|
| M2x12 | 12 |
| M2.5x20 | 20 |
| M3x30 | 25 |
| M4x30 | 30 |
| M5x30 | 30 |
| M6x30 | 11 |

There are three potential outcomes when testing a self-tapping screw:


- 1. The screw goes all the way in and is tightened with the set target torque. This is successful operation.
- 2. The screw breaks while screwing in and the Screwdriver returns a result code / runtime error: 10 "Torque dropped unexpectedly". This means that the screw cannot handle such high torque on a material that hard.
- 3. The Screwdriver stops halfway through and returns a result code / runtime error: 4 "Torque exceeded prematurely". This means that a higher torque is needed to go through that material with that screw. A solution could be to set a higher tightening torque.

For a successful tapping, ensure that the hole is made according to the screw manufacturer specifications.






Torque accuracy Metric



Torque accuracy US Standard



Screw-bit System

This system will highly increase the efficacy of the screws to be picked up, aligned with the bit, moved around with the Screwdriver and screwed in/out. Therefore, it is highly recommended to set up the Screw-bit System correctly to keep a high success rate.

Example of the Screw-bit System for an ISO 14579, M2 screw.







- 1 Screw
- 2 Screw fix
- 3 Screw carrier
- **4** Bit
- 5 Bit holder

The following sections explain the different components of the Screw-bit System and how to set it up correctly.

Screws

The first step is to know what type of screw is going to be used. The screw type will define what type of screw fix (in any), screw carrier, bit, and bit holder shall be used.



NOTE:

Use a chamfer for better reliability when making the screw hole.

The recommended screw types for the Screwdriver are the ones that have the properties mentioned previously in the **Supported Screws** tables.

Screw Fix and Screw Carrier


Select the right screw fix and screw carrier depending on the screw type and the size to maximize the efficacy of the Screw-bit System based on the table in section:


- Metric Screws
- US Standard Screws
- Self-tapping Screws for Aluminium
- Self-tapping Screws for Plastic





The screw fixes are needed for the DIN 912, ISO 4762, ISO 14579, ISO 14580, DIN 7981C / ISO 7049, DIN 7981F / ISO 7049, WN 5251, WN 1411, WN 5451 and ASME B18.3 HEX Cylinder screw types. The screw fixes have signifiers to show what size of screw they support.





The screw carriers also have signifiers to help identifying what screw type and size they can be used with.

| Screw thread size | Screw type illustration | |
|-------------------|--|--|
| M3 | ••••••••••••••••••••••••••••••••••••• | |

Bits

Select the right bit depending on the screw type and size to maximize the efficacy of the Screw-bit System based on the table in section:

- Metric Screws
- US Standard Screws
- Self-tapping Screws for Aluminium
- Self-tapping Screws for Plastic

The bits have signifiers to help identifying what bit type and size they are.





| Screw type standard | Shows bit size and type |
|--|-------------------------|
| Din 912 / ISO 4762 ASME B18.3 HEX Cylinder | 5 |
| ISO 14579 ISO 14580 ISO 14581 DIN 7500 M DIN 14586 C WN 5251 ISO 4042 WN 5451 ASME B18.6.3 Torx Button head ASME B18.6.3 Torx Counter sunk | T-30 |
| DIN 7985A DIN 7981C / ISO 7049 DIN 7981F / ISO 7049 DIN 7982 C DIN 7983 C WN 1411 ASME B18.6.3 Cross recessed Button head | РНЗ |

Supported bit shank properties:

- Type 1/4" HEX
- Length 25 mm



NOTE

Bits longer than 25 mm could be used. However, the screw carrier and the screw fix might not hold the screw properly in place.

Bit Holder

Select the right bit holder depending on the screw type and size to maximize the efficacy of the Screw-bit System based on the table in section:

- Metric Screws
- US Standard Screws
- Self-tapping Screws for Aluminium
- Self-tapping Screws for Plastic

The bit holder generates a magnetic force that will keep the screw attached and aligned to the bit.

There are two types of bit holders:





- **Bit Holder A**: Generates a higher magnetic force. It is commonly used for the bigger and heavier screws.
- **Bit Holder B**: Generates a lower magnetic force. It is commonly used for the smaller and lighter screws.




WARNING:

If Bit Holder A is used for smaller and lighter screws instead of Bit Holder B, the screws can jump from the Screw Feeder to the Screwdriver because of the higher magnetic force.

Bit Extenders 50 and 100 mm

The bit extenders are a long version of the previously described bit holders. Bit extenders are useful to reach narrow spaces.



The bit extenders have a lock nut to tighten against the screw carrier to ensure that the screw carrier does not move out of position over time.

When the bit extenders are mounted on the Screwdriver, the maximum total radial runout can be up to 0.5 mm (measured below the thread as shown in the following picture).



The bit extenders need to be purchased separately by contacting your vendor where the Screwdriver was purchased.

- Bit extender type A 50 mm PN 109301
- Bit extender type B 50 mm PN 109289
- Bit extender type A 100 mm PN 109290
- Bit extender type B 100 mm PN 109298

For more information on the mechanical dimensions, go to the Mechanical Drawings section.





Set up the Screw-bit System

1. Place the bit into the bit holder.



2. Place the screw carrier on the bit holder.




3. All screw carriers must be adjusted so that the screw head sits stable on the screw carrier avoiding a gap in between. This needs to be done to ensure high performance of the Screw-bit System.


See the pictures below as reference.

| Appearance | Adjustment method |
|------------|-------------------|
| | A |









4. When this is achieved, remove the screw and push in the screw fix (only Din 912, ISO 4762, ISO 14579, ISO 14580 and ASME B18.3 HEX Cylinder screw types).




The final setup of the Screw-bit System with the screw in place should look like in the pictures below.

Telefon: +420 416 711 333

E-mail: lin-tech@hennlich.cz






Attaching the Screw-bit System to the Screwdriver

To attach the Screw-bit System to the Screwdriver, follow the instructions below.

1. Move the shank to the highest possible value by using the user interface in the robot or in the Web Client.




2. Detach the Screwdriver from the Quick Changer.








3. Remove the lid.



5. Ensure that the bit holder is perfectly attached by gently shaking it to make sure it is not loose.


4. Place the hex shape of the bit holder inside of the end of the Screwdriver's shank. The system will be attached to the Screwdriver by a magnetic force.



Detaching the Screw-bit System from the Screwdriver

To remove the Screw-bit System from the Screwdriver's shank, follow the instructions below.

 Move the shank all the way out to the highest possible value by operating the user interface in the robot or in the Web Client.



 Use the provided key to grab the bit holder. While holding the key, move the shank inwards (to a lower value) by operating the user interface in the robot or in the Web Client.




Overview of the Items Needed Depending on the Screw Type and Size

In the following tables, an overview is shown of the items needed depending on the screw type and size. Based on what screw type and size you have, search for the screw standard and the thread size and find what kind of bit, screw fix, screw carrier and bit holder you will need.








For more information, see the example.

Items Needed Depending on Screw Type and Size for Metric Screws

| Items Needed Depending on Screw Type and Size for Metric Screws | | | | | |
|---|-----------------------------|-------------------------|----------------|--------------|------------------|
| Head type | | Cylinder | | Counter sunk | Button head |
| Screw standard | Din 912 / SO 4762 | ISO 14579 | ISO 14581 | DIN 7985A | |
| Thread Size | Bit holder, bit, s | crew carrier and | screw fix need | ed | |
| M1.6 | © S1.5 M1.6 M1.6 B | N/A | N/A | N/A | |
| M2 | ⊚ S1.5 M2 M2-3 A | © T6 M2 M2-3 A | N/A | © T6 | ⊕ PH1 M2 B |







Items Needed Depending on Screw Type and Size for US Standard Screws

| Items Needed Depending on Screw Type and Size for US Standard Screws | | | | | | | |
|--|--|--------------------------------|--------------------------|----------------------|-----------------|--|--|
| Head type | Cylinder | Button | Button head Counter sunk | | | | |
| Screw standard | ASME B18.3 | ASME B18.6.3 Cross recessed | ASME B18.6.3 | ASME B18.3 HEX | ASME B18.6.3 | | |
| Thread Size | hread Size Bit holder, bit, screw carrier and screw fix needed | | | | | | |





| Items | Items Needed Depending on Screw Type and Size for US Standard Screws | | | | | |
|-------|--|-------------------|-------|--------------------|-------|--|
| 1# B | ⊚ H1/16" ► 1# | N/A | N/A | N/A | N/A | |
| 2# B | © H5/64" | | © T8 | N/A | © T6 | |
| 4# B | H3/32" | | © T10 | ◎ H1/16" ►•• 4# | © T8 | |
| 6# | ⊚ H7/64" | | © T15 | ◎ H5/64" ►• 6# | © T10 | |
| 8# | ⊚ H9/64" ■ 8#-1/4" | | © T20 | ⊚ H3/32" ▶•• 8# | © T15 | |
| 10# | ⊚ H5/32" | ⊕ PH2 □ ■ 10# | © T25 | ⊚ H1/8" 10# | © T20 | |
| 12# | N/A | | © T27 | N/A | N/A | |



| Items | Items Needed Depending on Screw Type and Size for US Standard Screws | | | | | |
|-------|--|-----|-----|---------------|-----|--|
| 1/4" | ⊚ H3/16" | N/A | N/A | ⊚ T30 1/4" | N/A | |

Items Needed Depending on Screw Type and Size for Self-tapping Screws for Aluminium

| Items Needed Depending on Screw Type and Size for Self-tapping Screws for Aluminium 1/2 | | | | | | |
|---|-------------------------|-------------------------|------------------------|------------|--|--|
| Head type | Pan | head | Flat round with flange | Lens head | | |
| Appearance | | | | | | |
| Standard | DIN 7981 C/ ISO 7049 | DIN 7981 F/ ISO 7049 | WN 5251 | DIN 7983 C | | |
| Thread Size | Bit, screw carrier a | nd screw fix needed | 1 | | | |
| ST2.2 / 2.2 / KB22 / K22 | | | N/A | | | |
| ST 2.9 | | | N/A | ⊕ PH1 ■ 4# | | |





| Items Needed Depending on Screw Type and Size for Self-tapping Screws for Aluminium 1/2 | | | | |
|---|-----|-------|---------------------|-----|
| 3 / M3 / KB30 / K30 | N/A | N/A | © T10 M4 M4-6 | N/A |
| ST3.5.3 / 3.5 / KB35 / K35 | | ⊕ PH2 | © T10 M4 M4-6 | |
| ST 3.9 | N/A | | N/A | N/A |
| 4 / M4 / KB40 / K40 | N/A | N/A | © T20 M5 M4-6 | N/A |
| ST 4.2 | | | N/A | |



| Items Needed De | pending on Screw T | ype and Size for Se | elf-tapping Screws | for Aluminium |
|-------------------------|--------------------|---------------------|---------------------|-----------------------------------|
| ST 4.8 | | N/A | N/A | PH210# |
| 50 / M5 / KB50 / K50 | N/A | N/A | © T25 M6 M4-6 | N/A |
| ST 5.5 | | N/A | N/A | N/A |
| ST 6.3 | | N/A | N/A | N/A |

| Items Needed Depending on Screw Type and Size for Self-tapping Screws for Aluminium 2/2 | | | |
|---|---|--------------|------------|
| Head type | | Counter sunk | |
| Appearance | Counter sunk O O O O O O O O O O O O O | | |
| Standard | DIN 7500 M | DIN 14586 C | DIN 7982 C |






| Items Needed Depending on Screw Type and Size for Self-tapping Screws for Aluminium 2/2 | | | | |
|---|------------|------------|-------------|--|
| Thread Size Bit, screw carrier and screw fix needed | | | | |
| 20 / M2 / K20 | © T6 ▶ M2 | N/A | N/A | |
| ST2.2 / 2.2 / KB22 / K22 | N/A | © T6 ■ M2 | | |
| 2.5 / M2.5 / KB25 / K25 | © T8 | N/A | N/A | |
| ST 2.9 | N/A | © T8 | | |
| 3 / M3 / KB30 / K30 | © T10 M3 | N/A | N/A | |
| ST3.5.3 / 3.5 / KB35 / K35 | N/A | © T15 | ⊕ PH2 ►• 6# | |



| Items Needed Depending on Screw Type and Size for Self-tapping Screws for Aluminium 2/2 | | | | |
|---|-----------------------|----------------|-----------|--|
| ST 3.9 | N/A | © T15 ▶• 6# | | |
| 4 / M4 / KB40 / K40 | © T20 ►○ 6# | N/A | N/A | |
| ST 4.2 | N/A | © T20 | | |
| ST 4.8 | N/A | © T25 | | |
| 50 / M5 / KB50 / K50 | © T25 | N/A | N/A | |
| ST 5.5 | N/A | © T25 | ⊕ PH3 10# | |







Items Needed Depending on Screw Type and Size for Self-tapping Screws for Plastic

| Items Needed Depending on Screw Ty | pe and Size for S | Self-tapping Scre | ws for Plastic |
|--|---|-------------------|----------------|
| Head type | Counter sunk Flat round with flange | | |
| Appearance | | | |
| Standard | ISO 4042 | WN 1411 | WN 5451 |
| Thread size and Bit holder/ Bit extender | Bit, screw carrier and screw fix needed | | |
| 20 / M2 / K20 | N/A | N/A | © T6 |
| ST2.2 / 2.2 / KB22 / K22 | © T6 | N/A | © T6 |



| Items Needed Depending on Screw Ty | pe and Size for S | elf-tapping Scre | ws for Plastic |
|------------------------------------|-------------------|------------------|---------------------|
| 2.5 / M2.5 / KB25 / K25 | | | |
| | © T8 | ⊕ PH1 | |
| A | M2.5 | • M2 | 2 |
| 3 / M3 / KB30 / K30 | | | |
| A | © T8 M3 | | © T10 ■ 4# |
| ST3.5.3 / 3.5 / KB35 / K35 | | | |
| A | © T15 | | N/A |
| 4 / M4 / KB40 / K40 | | | |
| A | © T20 | | © T20 M4 M4-6 |
| 50 / M5 / KB50 / K50 | | | |
| A | N/A | | © T25 |
| 60 / M6 | | | |
| A | N/A | N/A | © T30 |
| | | | |







Screwdriver Position to Execute Commands

To successfully execute the Screwdriver commands, it is fundamental to position the Screwdriver correctly. This is achieved if the following two conditions are met:

1. The Screw-bit System must be perfectly aligned to the screw or thread.




2. The distance between the Screwdriver's bottom part and the surface where the action takes place must be within the range of 0-8 mm [0-0.31 inches].



To successfully execute the Screwdriver commands, it is fundamental to operate the Screwdriver downwards or maximum sidewards. The Screwdriver should not be operated upwards or with an angle higher than 90° orientate with respect to the ground, since this will trigger the protective feature.







Ground

LED - Device Status

The screwdriver has a LED that shows the device status.

| Color | Device Status | |
|-----------------|--------------------------------|------------------|
| O No light | Power missing | |
| Steady green | Ready to work - Idle - Static | |
| Blinking green | Initializing | |
| Steady orange | Busy – Moving/rotating shank | (n)robot |
| Blinking orange | Operational malfunction | |
| Steady red | Not working – Hardware problem | V |
| Blinking red | Safety – Emergency stop | |

Telefon: +420 416 711 333

E-mail: lin-tech@hennlich.cz





Torque Angle Curve and Torque Gradient

The torque gradient shows how the torque is applied in the last phase of the Tightening screw command. This could be used as an indicator to detect if a Tightening command is performed correctly.



NOTE:

When using self-tapping screws, if the tapping torque is very close to the target torque, the torque gradient might provide an invalid value.


For instance, the torque gradient could be different if:

- · The hole thread is not long enough
- The hole thread is different from the screw thread
- · The hole thread is not clean (for instance by deburrs from CNC machining)
- The friction between the screw thread and the hole thread is too low or too high
- The friction between the screw head and the tighten part is too low or too high

A torque gradient variable is made available to be checked in the robot program.

The graph below shows a normal Torque/Angle curve. In this case has been made with an M4 screw and 2.4 Nm as target torque.


Torque angle curve Metric







Torque angle curve US Standard




Adjusting the Bellow back in Place



NOTE:

Initially, the bellow should not come out of place, but if it does, follow the instructions below to adjust it back in place.

1. Remove the lid.



2. Move the shank to the highest possible value by using the user interface in the robot or in the Web Client.






3. Adjust the bellow back in place.




4. Place the lid back on.





ŽIJEME TECHNIKOU



1.2. Screwdriver







All dimensions are in mm and [inches].

